

**Two
dots**



ONEKICK **two** **ELECTRIC SCOOTER**

INSTRUCTION MANUAL

INTRODUCTION

Congratulations on the purchase of your new Onekick Two!

Easy and fun to use, yet convenient to carry with you anywhere you go. Onekick pro will allow you to move around effortlessly by exploiting cutting-edge, green technology.

This manual will help you understand how to use the device properly. Please read it carefully, comply with all the safety rules and pay attention every time you decide to use your Onekick Pro. You are about to embark on a unique and exciting experience!

SAFETY

Before getting on your Onekick Two, please read these instructions carefully. You should pay attention and stay focused at all times when using your device, even after you have become more acquainted with it.

Read this manual carefully and keep it for future reference. The reseller shall not be liable if the product is used in any way that is not compliant with its intended use or if the instructions in this manual are not respected.

WARNING

Onekick Two may be dangerous if you do not pay due attention and care. Make sure you have read the manual before using your Onekick Two. Pay special attention to the following:

- Always check the battery level before use. Do not use if the battery is discharged or if its level is below 20%.
- Find out about local laws to understand how and where to use the Onekick Two in legal ways and always follow the relevant regulations.
- Avoid obstacles, slippery surfaces, cracks or steep climbs.
- Avoid roads and surfaces with water, sand, leaves and other debris.
- Do not immerse in water.
- Do not exceed the maximum load of 100Kg (including additional weights): exceeding the load limit may cause damage to the vehicle and the rider.
- Onekick Two is not intended for children: only riders over the age of 13 should use it, and it is important that you determine whether the rider meets the necessary requirements in terms of coordination, physical strength and maturity before boarding.
- It is absolutely forbidden to use and transport two or more people.
- Wear safety equipment such as helmets, knee pads and elbow pads to prevent injury of any kind.
- Wear closed shoes.
- Do not use it in poorly lit areas, close to other vehicles. avoid jumps or ramps.
- Avoid jumps or ramps.
- Always drive with caution and responsibility, avoiding using your scooter in bad weather and on dangerous road surfaces.
- Do not use the device if you are under the influence of alcohol or drugs, nor if you are not in top physical shape or are pregnant.
- Stay alert and concentrated to avoid collisions with people, animals and surrounding objects.
- Do not use headsets or smartphones while operating your device.
- Pay attention to speed, keep the right speed and pay attention to the safety distance, so as to avoid as much as possible braking too abruptly.
- Respect pedestrians and give them priority.
- Before using the product, please check that the screws are firmly tightened.
- Do not modify the product except in accordance with the manufacturer's instructions.
- Check the product periodically. Replace worn or broken parts immediately.
- When using the product, keep hands and fingers away from wheels and other moving parts to avoid the risk of crushing.

COMPONENTS

1. Handlebar with antislip grips.
2. Handlebar.
3. Steering and folding system.
4. Stand.
5. Back pedal brake.
6. Power supply.
7. Connection wire.



ASSEMBLY

The packaging will contain disassembled grips, electric brake and display. To assemble the product, follow these instructions carefully.

- Stand behind the scooter and insert the electrical brake on the left-hand side of the handlebar and the LCD display on the right-hand side.
- Screw them on to the bar with the included screws.
- Screw the handles onto the handlebar making sure you insert them in the right direction.



UNFOLDING/FOLDING THE SCOOTER

- Push the unlocking button and lift the steering rod upwards to unfold the scooter. You will know that the scooter has unfolded entirely when you hear a click as it locks into place. Make sure it is entirely unfolded and secured before you get on.
- To fold the scooter, push the unlocking button and lower the steering rod until you hear a click.



CHARGING THE BATTERY

- It is advisable to charge the battery fully before first use.
- Insert the charger cable into the plug in the centre of the handlebar.
- While charging, the LED light will be red.
- Once the battery has been fully charged, the LED lights will turn green.
- A full charge will take about 3 hours.



WARNING

- Reduced battery autonomy in winter is perfectly normal since the battery performance decreases in cold weather.
- Store the product with the charged battery. Leaving the product with discharged battery or with battery level close to 0% over long periods of time may cause damage to the battery. Recharge the device at least once a month even if you did not use it.
- Keep the device in a sheltered, cool and dry place. Wet places may cause condensation inside the battery and damage it.
- Recharge the battery in a clean, dry place, away from inflammable objects, heat sources and direct sunlight.
- Do not overcharge the batteries.
- Do not recharge at temperatures close to 0°C.
- Use the provided power supply only.
- Do not use the device while it is charging.

TURNING YOUR SCOOTER ON AND OFF

To turn Onekick Two on and off push the central button on the display for a few seconds. The display will light up to confirm that the scooter has been turned on.

Onekick Two is equipped with an LED light on the front. You can also turn the LED light on and off by means of the dedicated button on the handlebar.

SELECT SPEED

Onekick Two has three speed levels, which you can select by pressing the upper or lower button on the display one or several times.

Press the upper button to increase speed from level 1 to level 3. Level 1 indicates low speed, level 2 indicates intermediate speed and level 3 indicates high speed.

Press the lower button on the display to decrease the level of speed.

It is advisable to move gradually, starting from low speed and gradually increasing the speed to the other two levels only after you have become well acquainted with the device.

CHANGE THE DISPLAY MODE

Change the information on the display by pressing the ON/OFF switch to pass from one mode to the other:

DIS: distance covered

TIME: amount of time the device has been used

ODO: total distance covered

VOL: voltage during use

RPM: engine revolutions per minute



GUIDE

- Hold the handlebar with both hands and place one foot on the platform.
- Use the foot on the ground to push yourself forward and take off. Then push the accelerator lever on the handlebar. Once you reach a speed of 3 Km/h the engine will start.
- Especially when you are still learning to use the vehicle, try to moderate your speed to become more familiar with the device.
- To slow down, you can use either the electrical or the mechanical brake.
- To use the electrical brake, you need to push down the lever on the left-hand side of the handlebar while driving and be careful not to push too hard and too abruptly to avoid blocking the wheel.
- The mechanical brake is located on the rear wheel and can be activated by pushing on the wheel cover with your rear foot. The pressure will slow down the scooter.

REMEMBER

Onekick Two is designed for indoor use and for use on smooth outdoor surfaces. Always pay attention to the ground where you are about to move and avoid wet, irregular and slippery surfaces at all times, as well as ramps, jumps and obstacles in general.

If a surface suddenly becomes, stop using the device immediately to prevent any falls.

The wheels of Onekick Two must always be on the ground for the device to work properly. Otherwise, you can lose grip and this would cause potential falls. Avoid sudden manoeuvres and impacts of all kinds to prevent any grip losses.

Onekick Two is not approved for road use and it must be used in private and pedestrian areas only, after checking the local rules. Children using the device must be supervised by an adult.

DISPLAY LCD

Onekick Two is equipped with an LCD display that shows the battery charge level, the speed, the speed selector, and other data. The display also features three buttons to turn the display on and change the settings.



MAINTENANCE

Store the device in a dry place, away from any heat sources and direct sunlight.

A long exposure to UV rays, rain and atmospheric agents may damage the materials that make up the vehicle.

If you do not recharge the lithium ion batteries for long periods of time, they tend to discharge automatically.

Full battery discharge or battery levels close to 0% may damage the battery and make it unfit for future use.

It is advisable to charge the battery at least once a month. If required, clean the device with a wet cloth. When you do so, the device must be switched off and disconnected from the power supply. Do not spray low- or high-pressure water directly on the device and do not plunge it into water or any other liquids..

WARRANTY

Please, keep the payment receipt as a proof of purchase so that you are entitled to warranty pursuant to the law. The warranty is structured as follows:

- **2 years' warranty for the vehicle, except for the battery and tyres.**
- **6 months' warranty for the battery, engines and tyres.**

Warning – The warranty does not cover the following conditions:

- Malfunctioning caused by incorrect use.
- Malfunctioning caused by unauthorized changes, by the disassembly of components or by reparations completed by the user.
- Damage or malfunctioning originating from incorrect storage.
- No or non-compliant proof of purchase.
- Damage caused by use on improper surfaces.
- Damage caused by long use in the rain or by plunging the device into the water.

2018 Twodots

Twodots is a registered trademark of X-Joy Srl.

Produced and imported by X-Joy Srl – Via Sempione, 17 – 21011 Casorate Sempione (VA)

The product meets the essential requirements and all provisions of the following European Directives:
2011/65/EU.

Customer care: support@twodots.it

www.twodots.eu